

## ADJUSTING THE FOOT PEDALS

This fun kart has been assembled with foot pedals that can be moved so your child can grow with the kart. First remove the bolts (A) and (B) shown in the figures below. Remember not to take the pedals off the rod, by doing so the springs can become loose. Once you have done this, you are able to move the cable holder and the pedal rod (C) with the pedals together. Holes (1) and (3) are for the pedal rod alternative positions; holes (2) and (4) are for the cable holder. There is only one bolt that holds the pedal rod in place. On the brake pedal side there is a slot for the pedal rod to fit into. Once you have picked out the holes for setting the pedals, just slide the pedal rod and cable holder together then fasten all bolts and nuts. Make sure after you have done the adjustment, the pedals are working and spring back to their original positions.

