Operator's Manual SUPPLEMENT

MANCO MODEL NO. 388-38

WARNING: Read Engine Owner's Manual, Vehicle Operator's Manual, and Supplement Carefully Before Operating Vehicle.

Parts List



ORDERING PARTS



Seek Part(s) from your models illustrated diagram, cross over REF# to PART#
Type PART# into sites [Search Box] at GoKartsRus.com OPEN IN NEW TAB CONTROL CLICK LINK, SELECT
Add all needed parts to Shopping Cart | Complete "Checkout" \ Done!


If a part does not come up in a Site Search, please Contact Us (include part# in email)


BEFORE OPERATING THIS VEHICLE, THE OWNER AND/OR OPERATOR MUST UNDERSTAND THE VEHICLE WAS NOT DESIGNED OR MANUFACTURED TO MEET SPECIFICATIONS FOR USE ON PUBLIC ROADS, STREETS, HIGH-WAYS, OR THOROUGHFARES AND HAVE READ AND HAVE AN UNDERSTANDING OF ALL THE INSTRUCTIONS FOR SAFE ASSEMBLY AND OPERATION AS WELL AS THE INSTRUCTIONS GOVERNING THE ENGINE AND OTHER PORTIONS OF THE VEHICLE.

REPAIR PARTS - 388-38

.

				055	DADT	
	REF.	PART		REF.	PART	RECORDING
	NO.	<u>NO.</u>	DESCRIPTION	<u>NO.</u>	NO.	DESCRIPTION
(1	8694-2	Frame - Black	69	4660	Spacer, 1" ID x 4-7/16"
	2	8196	Engine, 8HP Tecumseh	70	K388-38	Axle Guard Repair Kit
	3	5160	Seat Bottom	71 72	6573 6617	Bolt, 5/16-18 x 1-3/4" Bearing Flange
	4 5	8748 9343	Seat Back Chain, 420 x 72 Links (incl. 6)	72	3941	Bearing, 1" ID
	6	2037	Master Link, 420 Chain	74	8223H	Axle Shaft
	7	9522-2	Center Bar	ASM	6420	Sprocket Asm. (incl. 75-78)
	8	9527-2	Rear Bar	75	9006	Bolt, 1/4-20 x 1/2" Flanged Whiz
	9	6320	Headrest	76	6282	Sprocket, 420 x 54 Teeth
	10	9525-2	Overhead Bar	77	6701	Bolt, 5/16 x 1-1/4" Socket Head
	11	9524-2	Front Bar	78	6280	Sprocket Hub
	12	1854	Washer, No. 14 Flat	79	9680	Key, 1/4 x 3/8 x 1-1/4"
	13	1849	Bolt, 1/4-20 x 1-1/2"	80	1775	Key, 1/4 sq. x 1-1/4"
	14	6452	Boit, 3/8-16 x 5"	81	6314H	Brake Rotor
	15	9085	Nut, 3/8-16 Toplock	82 83	2265 1263	Spacer, 1" ID x 3/4" Nut, 5/16-18 Flanged Whiz
	16	2386	Bolt, 3/8-16 x 3-1/2" Bolt, 1/4-20 x 3/4" Flanged Whiz	84	9674	Spacer, 3/8 ID x 3/8"
	17 18	5839 9176	Bolt, 5/16-18 x 1"	85	8197	Brake Caliper Asm.
	19	9145	Bolt, 3/8-16 x 1-3/4"	86	9856	Arm Pad Cover
	ASM	6430	Tie Rod Asm. (incl. 20-24)	87	9759B	Foam, 30" Black
	20	6431	Tie Rod	88	9777	Plastic Hose Clamp, 7/8" ID
	21	9092	Nut, 3/8-24 RH Jam	89	9808B	Foam, 10" Black
	22	1414	Rod End - RH	90	9758B	Foam, 43" Black
	23	9024	Nut, 3/8-24 LH Jam	91		
	24	1415	Rod End - LH	92 93		
	25	9146	Bolt, 3/8-16 x 1-1/2" Stearing Wheel	93 94		
	26 27	6038 9080 -	Steering Wheel Bolt, 1/4-20 x 2-3/4"	95		
	28	9160	Bolt, 1/4-20 x 7/8" Nylock	96		
	29	9799	Stop Switch Assembly	97		
	30	9172	Bolt, 3/8 x 1/4 Shoulder	98		
	31	6441	Washer, 3/8 ID Spring	99		
	32	6440	Nut, 5/16-18 Jam	100		
	33	6773-2	Parking Brake Handle	101		
· · · ·	34	6442	Brake Handle Cover	102		
	35	9057	Nut, 1/4-20 Toplock	103		
	36	8215-2	Rear Brake Rod	104 105		
	37 38	8715-2 9869	Front Brake Rod Spacer, 1/4 ID x 5/16 OD x 5/8"	106		
	39	9502	Spring, Left Wound	107		
	40	1436	Pedal, Brake	108		
	41	1847	Bolt, 1/4-20 x 1"	109	-	
	42	1189	Nut, 5/16-18 Toplock	110		
	43	9091	Washer, 3/8 Flat	111		.
	44	1447	Pedal Bolt	NI	9677	Decal, Warning: Hot Surfaces (on engine)
	45 46	1443 6395-2	Nut, 1/4-20 Acorn Front Plate - Black	NI	9678 5964	Decal, Warning: Engine Exhaust (on engine)
	46 47	5682	Bolt, 1/2-13 x 5-1/2"	NI 112	6540	Decal, Oil Warning (on engine) Decal, Warning: Wear Helmet
	48	9022	Washer, 1/2 Flat	113	1689	Decal, Steering Wheel
	49	1012	Nut, 1/2-13 Toplock	114	2873	Decal, Trailer Load
	50	2457	Spindle, Right	115	8138	Decal, Warning: Entanglement
	NI	2458	Spindle, Left	116	4504	Decal, Yellow Warning
	51	5157	Spacer, 5/8 ID x 3/4"	117	2832	Decal, No Passengers
	52	1437	Pedal, Throttle	118	8153	Decal, Age Restriction
	53	1389	Bushing, 1/4 ID x 5/16"	119	1441	Decal, Front Floor Pan
	54	9503 9345	Spring, Right Wound	120	1688	Decal, Front Plate
	55 56	9345 5090	Throttle Cable Bearing, 5/8 ID	121	9834-2	Steering Crank Weldment
	57	5950	Spanner, 5/8 ID x 2-1/8"	122 123	9873 9872	Cam Follower Bearing
	58	9309FP	Wheel Assembly, Front	123	9871	Washer, 1/4 Flat Shoulder Bolt, 1/2 x 3"
	59	1046	Nut, 5/8-11 Toplock	125	9709	Compression Spring
	60	3802	Inner Tube, 6"	NI	9247R4	Assembly Instructions
	61	4915	Tire, 145/70 x 6 Knobby	NI	6477	Dingo Operator's Manual
	62	9162	Nut, 3/4-10 Toplock	NI	8220	Tecumseh Engine Manual
	ASM	1412	Wheel Asm, Rear (Incl. 63-65)			~
a'	63	1452	Tire, 22 x 11 - 8 Tubeless		= Assembly	
	64	1430	Inner Tube, 8" (Repair Part Only)	NI = N	lot Illustrated	
	65	1451	Wheel Rim, 8"			
	66 67	1428	Nut, 1/2-13 Cone Wheel			
	67 67	1557	Wheel Hub w/Studs			
	68	6123	Key, 1/4 sq. x 1-3/4"			





REF. NO 1 2 3 ASM 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	PART NO 8689 1130 2468 2594 * 2472 2470 2477 2477 2474 2475 * 9125 1082 6814 9101 9060 8745 8196 2449 9006 8739	DÉSCRIPTION Stud, 3/8-24 x 4-1/4" Washer, 3/8 Split Lock Washer, Pilot Driver Pulley Assembly (incl. REF. 4-12) Cover and Drive Plate Extension Spring Cam Roller Spring Clip Moveable Face and Hub Guide Bushing Compression Spring Retaining Ring Fixed Face and Post Washer, 3/8 Flat Spacer, 1" ID x 7/16 Belt, Symmetrical Bolt, 5/16-24 x 3/4" Washer, 5/16 Plain Cover Panel Engine, 8HP Tecumseh Nut, Tinnerman Bolt, 1/4-20 x 1/2" Whiz Cover Assembly	REF. NO 23 24 25 26 27 28 29 30 ASM 31 32 33 34 35 36 37 38 39 40 41 42 43 44	PART NO 8600 1263 2388 9123 9186 8908 9155 4914 8664 * 1031 2483 * 2516 2480 * 2478 2477 3403 8854 1119 3887 1125S	DESCRIPTION Impeller Nut, 5/16-18 Flange Nut, 3/8-24 Hex Nut, 3/8-24 Toplock Hex Bolt, 5/16-18 x 1-1/2" Chassis Nut, 5/8-11 Jam Spacer, 1" ID x 9/16 Driven Pulley Assembly (incl. REF. 31-39) Fixed Face and Post Key, 3/16sq x 1/2" Spacer Moveable Face and Cam Button Insert Torsion Spring Fixed Cam Thrust Washer Retaining Ring Key, 3/16sq x 2" Jackshaft, 13.69" Spacer, 5/8ID x 1/8" Spacer, 1" ID x 1/16 Sprocket, 9T #420		PART <u>NO</u> 5090 2430 8194 8443 8924 8923 8266 8227 1049 4912 8138 6958 8441 9176 9030 9677 9678 5964 Not Availabl Y = Assembly	
---	--	---	--	--	---	--	--	--