## **Operator's Manual** SUPPLEMENT


MANCO MODEL NO. 390-01

WARNING: **Read Engine Owner's Manual**, Vehicle Operator's Manual, and **Supplement Carefully Before** Operating Vehicle.

Parts List



BEFORE OPERATING THIS VEHICLE, THE OWNER AND/OR OPERATOR MUST UNDERSTAND THE VEHICLE WAS NOT DESIGNED OR MANUFACTURED TO MEET SPECIFICATIONS FOR USE ON PUBLIC ROADS, STREETS, HIGH-WAYS, OR THOROUGHFARES AND HAVE READ AND HAVE AN UNDERSTANDING OF ALL THE INSTRUCTIONS FOR SAFE ASSEMBLY AND OPERATION AS WELL AS THE INSTRUCTIONS GOVERNING THE ENGINE AND OTHER PORTIONS OF THE VEHICLE.



## REPAIR PARTS - 390-01

			·			
	REF.	PART		REF.	PART	DESCRIPTION
	NO.	NO.	DESCRIPTION	<u>NO.</u>	<u>NO.</u>	DESCRIPTION
بال مساعد	1	8694-2	Frame - Black	69	4660	Spacer, 1" ID x 4-7/16"
	2	8189	Engine, 10HP Tecumseh	70	K390-01 6573	Axle Guard Repair Kit Bolt, 5/16-18 x 1-3/4"
	3	5160	Seat Bottom	71 72	6617	Bearing Flange
	4	8748	Seat Back	72	3941	Bearing, 1" ID
	5 <sup>`</sup>	9343	Chain, 420 x 72 Links (incl. 6)	74	8223H	Axle Shaft
	6	2037	Master Link, 420 Chain	ASM	6420	Sprocket Asm. (incl. 75-78)
	7	9522-2	Center Bar Rear Bar	75	9006	Bolt, 1/4-20 x 1/2" Flanged Whiz
	8	9527-2	Headrest	76	6282	Sprocket, 420 x 54 Teeth
	9	6320 9525-2	Overhead Bar	77	6701	Bolt, 5/16 x 1-1/4" Socket Head
	10	9523-2 9524-2	Front Bar	78	6280	Sprocket Hub
	11 12	1854	Washer, No. 14 Flat	79	9680	Key, 1/4 x 3/8 x 1-1/4" Key, 1/4 sq. x 1-1/4"
	13	1849	Bolt, 1/4-20 x 1-1/2"	80	1775 6314H	Brake Rotor
	14	6452	Bolt, 3/8-16 x 5"	81 82	2265	Spacer, 1" ID x 3/4"
	15	9085	Nut, 3/8-16 Toplack	83	1263	Nut, 5/16-18 Flanged Whiz
	16	2386	Bolt, 3/8-16 x 3-1/2"	84	9674	Spacer, 3/8 ID x 3/8"
	17	5839	Bolt, 1/4-20 x 3/4" Flanged Whiz Bolt, 5/16-18 x 1"	85	8197	Brake Caliper Asm.
	18	9176	Bolt, 3/8-16 x 1-3/4"	86	6497	Arm Pad Cover
	19 ASM	9145 6430	Tie Rod Asm. (incl. 20-24)	87	6524	Foam, 26" Black
	ASM 20	6430 6431	Tie Rod	88	9777	Plastic Hose Clamp, 7/8" ID
	20	9092	Nut, 3/8-24 RH Jam	89	9808B	Foam, 10" Black Foam, 43" Black
	22	1414	Rod End - RH	90	9758B 6305-2	Tail Light Bracket
	23	9024	Nut, 3/8-24 LH Jam	91 92	6508	Tail Light Assembly
	24	1415	Rod End - LH	92	9106	Bolt, #10-32 x 1/2"
	25	9146	Bolt, 3/8-16 x 1-1/2"	94	6319	Tail Light Ground Wire
-	26	6038	Steering Wheel	95	6039	Washer, #10 Internal Lock
	27	9080	Bolt, 1/4-20 x 2-3/4" Bolt, 1/4-20 x 7/8" Nylock	96	6193	Nut, #10-32 Acom
	28	9160	Stop Switch Assembly	97	6383	End Cap
	29	9799	Boit, 3/8 x 1/4 Shoulder	98	6364	Headlight Assembly
_	30	9172 6441	Washer, 3/8 ID Spring	99	6046	Bolt, #10-24 x 1/2"
1	31 32	6440	Nut, 5/16-18 Jam	100	5135	Nut, #10 Tinnerman
*	33	6773-2	Parking Brake Handle	101	6391	Light Switch Assembly Cover Plate
	34	6442	Brake Handle Cover	102	9528-2 6344	Start Switch w/Key
	35	9057	Nut, 1/4-20 Toplock	103 104	6313	Choke Cable
	36	8215-2	Rear Brake Rod	105	6353	Washer, Square Hole
	37	8715-2	Front Brake Rod Spacer, 1/4 ID x 5/16 OD x 5/8"	106	6296-2	Control Box
	38	9869	Spring, Left Wound	107	2290	Ignition Key
	39	9502 1436	Pedal, Brake	108	9430	Battery Hold Down Rod
	40 41	1847	Bolt, 1/4-20 x 1"	109	3633	Battery
	42	1189	Nut, 5/16-18 Toplock	110	9642-2	Battery Clamp Bar
	43	9091	Washer, 3/8 Flat	111	9468	Nut, #10-32 Nylock Wing Decal, Warning: Hot Surfaces (on engine)
	44	1447	Pedal Bolt	NI	9677 9678	Decal, Warning: Engine Exhaust (on engine)
	45	1443	Nut, 1/4-20 Acorn	NI	5964	Decal, Oil Warning (on engine)
	46	6395-2	Front Plate - Black	NI 112		Decal, Warning: Wear Helmet
	47	5682	Bolt, 1/2-13 x 5-1/2"	112		Decal, Steering Wheel
	48	9022	Washer, 1/2 Flat Nut, 1/2-13 Toplock	113		Decal, Trailer Load
	49 50	1012	Spindle, Right	115	8138	Decal, Warning: Entanglement
	50 MI	2457 2458	Spindle, Left	116		Decal, Yellow Warning
	NI 51	2458 5157	Spacer, 5/8 ID x 3/4"	117		Decal, No Passengers
	52	1437	Pedal, Throttle	118		Decal, Age Restriction
	53	1389	Bushing, 1/4 ID x 5/16"	119		Decal, Front Floor Pan
	54	9503	Spring, Right Wound	120		Decal, Front Plate Stooring Crank Weldment
	55	9345	Throttle Cable	121		Steering Crank Weldment Cam Follower Bearing
	56	5090	Bearing, 5/8 ID	122		Washer, 1/4 Flat
	57	5950	Spanner, 5/8 ID x 2-1/8"	123		Shoulder Bolt, 1/2 x 3"
	58	9309FP	Wheel Assembly, Front	124 125		Compression Spring
	59	1046	Nut, 5/8-11 Toplock	12	-	Decal, Floor Pan
	60	3802	Inner Tube, 6"	NI	-	Assembly Instructions
	61	4915	Tire, 145/70 x 6 Knobby	N		Dingo Operator's Manual
	62	9162	Nut, 3/4-10 Toplock Wheel Asm, Rear (incl. 63-65)	N		Tecumseh Engine Manual
	ASM	1412	Tire, 22 x 11 - 8 Tubeless			
· · · · · ·	63	1452 1430	Inner Tube, 8" (Repair Part Only)	AS	M = Assembly	
	64 65	1430	Wheel Rim, 8"		= Not Illustrated	l
	66	1431	Nut, 1/2-13 Cone Wheel			
	67	1557	Wheel Hub w/Studs			
	68	6123	Key, 1/4 sq. x 1-3/4"			
	00	0,20	•			

-

-----

\_

CALIPER BREAKDOWN 8 Æ 11


ģ


a

6

10

5





REF. NO 1 2 3 ASM 4 5 6 7 8 9 10 11 2 3 ASM 4 5 6 7 8 9 10 11 2 3 ASM 12 3 ASM 12 3 ASM 12 3 ASM 12 12 12 12 12 12 12 12 12 12	PART <u>NO</u> 8689 1130 2468 2594 • 2472 2470 2471 • 2474 2474 2474 2474 2475 • • 9125 1082 6814 9101 9060 8745 8189C 2449 9006 8739	DESCRIPTION Stud, 3/8-24 x 4-1/4" Washer, 3/8 Split Lock Washer, Pilot Driver Pulley Assembly (incl. REF. 4-12) Cover and Drive Plate Extension Spring Cam Roller Spring Clip Moveable Face and Hub Guide Bushing Compression Spring Retaining Ring Fixed Face and Post Washer, 3/8 Flat Spacer, 1" ID x 7/16 Belt, Symmetrical Bolt, 5/16-24 x 3/4" Washer, 5/16 Plain Cover Panel Engine, 10HP Tecumseh Nut, Tinnerman Bolt, 1/4-20 x 1/2" Whiz Cover Assembly	REF. NO 23 24 25 26 27 28 29 30 <b>ASM</b> 31 32 33 34 35 36 37 38 39 40 41 42 43 44	PART NO 8600 1263 2388 9123 9186 8908 9155 4914 8664 * 1031 2483 * 2483 * 2478 2478 2477 3403 8854 1119 3887 1125S	DESCRIPTION Impeller Nut, 5/16-18 Flange Nut, 3/8-24 Hex Nut, 3/8-24 Toplock Hex Bolt, 5/16-18 x 1-1/2" Chassis Nut, 5/8-11 Jam Spacer, 1" ID x 9/16 Driven Pulley Assembly (incl. REF. 31-39) Fixed Face and Post Key, 3/16sq x 1/2" Spacer Moveable Face and Cam Button Insert Torsion Spring Fixed Cam Thrust Washer Retaining Ring Key, 3/16sq x 2" Jackshaft, 13.69" Spacer, 5/8ID x 1/8" Spacer, 1" ID x 1/16 Sprocket, 9T #420		PART NO 5090 2430 8194 8443 8924 8923 8266 8227 1049 4912 8138 6958 8441 9176 9030 9677 9678 5964 = Not Availat SM = Assemb	DESCRIPTION Bearing Spanner Cap, Plastic Right Deck Cover Left Deck Cover Caliper Cover - Left Loop Clip Clip Nut Decal, Caution Decal, Warning: Guard Decal, Warning: Guard Decal, Warning: Long Hair Decal, Tire Pressure Caliper Cover - Right Bolt, 5/16-18 × 17 Washer, 5/16 Int. Lock Decal, Warning: Hot Surfaces Decal, Warning: Eng. Exhaust Decal, Oil Warning Decal, Oil Warning
--	--	--	--	--	---	--	--	---

-

تى يە


The web Har an

تغيسانية

WIRING DIAGRAM

m 3 -

-



REF <u>NO.</u> 1 2 3 <b>ASM</b> 4 5 6 7 8 9 10 11 <b>NI</b> <b>NI</b>	PART NO. 3611 3610 6516 9376P 9379 9381 9383 6386 9385 9377 8281 8108 6505 6897 6763	DESCRIPTION Battery Cable, Red 9 in. Battery Cable, Black 9 in. Battery Cable, Black 9 in. Battery Cable, Black 9 in. Wiring Harness (incl. 4-9) Wire, Taillight/Light Switch (Red) Wire, Taillight/Switch (Black) Wire, Engine/Switch (Black) Wire, Batt Gnd/Switch (Black) Wire, Solenoid/Switch (Blue) Wire, Solenoid/Light Switch (Red) Start Wire Adapter 1/4" Male Tab Terminal Poly Loom 43" Poly Loom 28" Poly Loom "Tee"		PART <u>NO.</u> 6508 6319 6344 6391 6364 2964 3633 2093 8216 2084 8202 9389 6304-2 Not Illustr					
<b>NI</b> 12	6813 6394	Poly Loom "Outlet" Stop Switch Assembly	ASM = Assembly						
<ul> <li>ORDERING PARTS</li> <li>1) Seek Part(s) from your models illustrated diagram, cross over REF# to PART#</li> <li>2) Type PART# into sites [Search Box] at CoKartsRus.com TPI-RGHT CLICK LINK, SELECT</li> <li>3) Add all needed parts to Shopping Cart   Complete "Checkout" / Done!</li> <li>If a part does not come up in a Site Search, please Contract Us (include part# in email)</li> </ul>									