Operator's Manual SUPPLEMENT

MANCO MODEL NO. 392-00

WARNING:
Read Engine
Owner's Manual,
Vehicle Operator's
Manual, and
Supplement
Carefully Before
Operating
Vehicle.

Parts List



ORDERING PARTS




2) Type PART# into sites [Search Box] at GoKartsRus.com OPEN IN NEW TAB OPEN IN NEW TAB OPEN IN NEW TAB

3) Add all needed parts to Shopping Cart | Complete "Checkout" | ✓ Done!

If a part does not come up in a Site Search, please Contact Us (include part# in email)


BEFORE OPERATING THIS VEHICLE, THE OWNER AND/OR OPERATOR MUST UNDERSTAND THE VEHICLE WAS NOT DESIGNED OR MANUFACTURED TO MEET SPECIFICATIONS FOR USE ON PUBLIC ROADS, STREETS, HIGH-WAYS, OR THOROUGHFARES AND HAVE READ AND HAVE AN UNDERSTANDING OF ALL THE INSTRUCTIONS FOR SAFE ASSEMBLY AND OPERATION AS WELL AS THE INSTRUCTIONS GOVERNING THE ENGINE AND OTHER PORTIONS OF THE VEHICLE.

5/99




REPAIR PARTS - 392-00

REF.	PART		REF.	PART	
NO.	NO.	DESCRIPTION DESCRIPTION	<u>NO.</u>	NO.	DESCRIPTION
1	10401-5	Frame - Red	71	6573	Bolt, 5/16-18 x 1-3/4"
2	10421	Engine, 12HP Tecumseh	72	6617	Bearing Flange
3	5557	Seat Bottom	73	3941H	Bearing, 1" ID
4	8748	Seat Back	74	8223H	Axle Shaft
5 6	9343 2037	Chain, 420 x 71 Links (incl. 6) Master Link, 420 Chain	ASM 75	6420H 9006	Sprocket Asm. (incl. 75-78) Bolt, 1/4-20 x 1/2" Flanged Whiz
7	8711-5	Center Bar	75 76	6282	Sprocket, 420 x 54 Teeth
8	8702-5	Rear Bar	77	6701	Bolt, 5/16 x 1-1/4" Socket Head
9	8735	Headrest	78	6280H	Sprocket Hub
10	8714-5	Overhead Bar	79	No constitute the same	
11	8710-5	Front Bar	80		
12 13	1854 1849	Washer, No. 14 Flat	81	6314H 2265	Brake Rotor
14	6452	Bolt, 1/4-20 x 1-1/2" Bolt, 3/8-16 x 5"	82 83	1263	Spacer, 1" ID x 3/4" Nut, 5/16-18 Flanged Whiz
15	9085	Nut, 3/8-16 Toplock	84	9674	Spacer, 3/8 ID x 3/8"
16	2386	Bolt, 3/8-16 x 3-1/2"	85	8197	Brake Caliper Asm.
17	5839	Bolt, 1/4-20 x 3/4" Flanged Whiz	86	8729	Arm Pad Cover
18	9176	Bolt, 5/16-18 x 1"	87	8726	Foam, 26" Gray
19	9145	Bolt, 3/8-16 x 1-3/4"	88	8730	Plastic Hose Clamp, 1-1/4" ID
ASM	6430	Tie Rod Asm. (incl. 20-24)	89 90	8732 8725	Foam, 9-1/2" Gray Foam, 37" Gray
20 21	6431 9092	Tie Rod Nut, 3/8-24 RH Jam	90 91	6305-2	Tail Light Bracket
22	1414	Rod End - RH	92	6508	Tail Light Assembly
23	9024	Nut, 3/8-24 LH Jam	93	9106	Bolt, #10-32 x 1/2"
24	1415	Rod End - LH	94	6319	Tail Light Ground Wire
25	9146	Bolt, 3/8-16 x 1-1/2"	95	6039	Washer, #10 Internal Lock
26	6038	Steering Wheel	96	6193	Nut, #10-32 Acorn
27	9080	Bolt, 1/4-20 x 2-3/4"	97	6880	End Cap
28	9160 9799	Bolt, 1/4-20 x 7/8" Nylock	98 99	6364 6046	Headlight Assembly
29 30	9799 9172	Stop Switch Assembly Bolt, 3/8 x 1/4 Shoulder	100	5135	Bolt, #10-24 x 1/2" Nut, #10 Tinnerman
31	6441	Washer, 3/8 ID Spring	101	6391	Light Switch Assembly
32	6440	Nut, 5/16-18 Jam	102	9528-2	Cover Plate
33	6773-2	Parking Brake Handle	103	6344	Start Switch w/Key
34	6442	Brake Handle Cover	104	8118	Choke Cable
35	9057	Nut, 1/4-20 Toplock	105	6353	Washer, Square Hole
36 37	8215-2 9638-2	Rear Brake Rod Front Brake Rod	106 107	6296-2 2290	Control Box Ignition Key
38	9869	Spacer, 1/4 ID x 5/16 OD x 5/8"	107	9430	Battery Hold Down Rod
39	9502	Spring, Left Wound	109	3633	Battery
40	1436	Pedal, Brake	110	9642-2	Battery Clamp Bar
41	1847	Bolt, 1/4-20 x 1"	111	9468	Nut, #10-32 Nylock Wing
42	1189	Nut, 5/16-18 Toplock	NI	9677	Decal, Warning: Hot Surfaces (on engine)
43	9091	Washer, 3/8 Flat	NI	9678	Decal, Warning: Engine Exhaust (on engine)
44 45	1447	Pedal Bolt	NI 112	5964 6540	Decal, Oil Warning (on engine)
46	10489-5	Front Plate - Red	113	1689	Decal, Warning: Wear Helmet Decal, Steering Wheel
47	5682	Bolt, 1/2-13 x 5-1/2"	114	2873	Decal, Trailer Load
48	9022	Washer, 1/2 Flat	115	8138	Decal, Warning: Entanglement
49	1012	Nut, 1/2-13 Toplock	116	4504	Decal, Yellow Warning
50	2457	Spindle, Right	117	2832	Decal, No Passengers
NI 51	2458 5157	Spindle, Left Spacer, 5/8 ID x 3/4"	118	8153	Decal, Age Restriction
52	1437	Pedal, Throttle	119	1441	Decal, Front Floor Pan
53	1389	Bushing, 1/4 ID x 5/16"	120 121	8830 9834-2	Decal, Front Plate Steering Crank Weldment
54	9503	Spring, Right Wound	122	9873	Cam Follower Bearing
55	9345	Throttle Cable	123	9872	Washer, 1/4 Flat
56	5090	Bearing, 5/8 ID	124	9871	Shoulder Bolt, 1/2 x 3"
57 50	5950	Spanner, 5/8 ID x 2-1/8"	125	1865	Bolt, 1/4-20 x 1-3/4"
58 50	9309FP 1046	Wheel Assembly, Front Nut, 5/8-11 Toplock	126	2257	Fairing
59 60	3802	Inner Tube, 6"	127 128	8734 9709	Fairing Decal
61	4915	Tire, 145/70 x 6 Knobby	129	10402-2	Compression Spring Seat Frame
62	9162	Nut, 3/4-10 Toplock	130	6734	Seat Slide - pair
ASM	1412	Wheel Asm, Rear (incl. 63-65)	131	8373	Seat Belt Shoulder / Lap
63	1452	Tire, 22 x 11 - 8 Tubeless	132	9188	Bolt, 1/2-13 x 1-1/2"
64	1430	Inner Tube, 8" (Repair Part Only)	NI	9247R4	Assembly Instructions
65 66	1451	Wheel Rim, 8" Nut, 1/2-13 Cone Wheel	NI	6477	Dingo Operator's Manual
66 67	1428 1557H	Wheel Hub w/Studs	NI	8121	Honda Engine Manual
68	9060	Washer, 5/16" Flat	ASM =	Assembly	
69	4660	Spacer, 1" ID x 4-7/16"		ot Illustrated	
70	K389-12	Axle Guard Repair Kit			




ASM 9810 B 1	rake Caliper (incl. 1-11) rake Pad Svc Kit (incl. 1-3) nvil w/Lining rake Lining acking Plate ctuator Pin djuster Pin ut, Jam olt, 3/8-16 x 2-1/4" ut, 3/8-16 x C-1/4"
--------------	--



REF. NO 1	PART <u>NO</u>	DESCRIPTION	REF. <u>NO</u> 23	PART <u>NO</u>	DESCRIPTION	REF. NO	PART NO	DESCRIPTION
	8689	Stud, 3/8-24 x 4-1/4"	23	8600	Impeller	<u>NO</u> 45	<u>NO</u> 5090	Bearing
2	1130	Washer, 3/8 Split Lock	24	1263	Nut, 5/16-18 Flange	46	2430	Spanner
3	2468	Washer, Pilot	25	2388	Nut, 3/8-24 Hex	47	8194	Cap, Plastic
ASM	2594	Driver Pulley Assembly	26	9123	Nut, 3/8-24 Toplock Hex	48	8878	Right Deck Cover
		(incl. REF. 4-12)	27	_{. 1} 9186	Bolt, 5/16-18 x 1-1/2"	49	8922	Left Deck Cover
4	*	Cover and Drive Plate	28%Lo	7-9186 7 -8908	Chassis	50	8921	Caliper Cover - Left
5	2472	Extension Spring	29	1466	Nut, 5/8-11 Flexlok Jam	51	8266	Loop Clip
6	2470	Cam Roller	30	4914	Spacer, 1" ID x 9/16	52	8227	Clip Nut
7	2471	Spring Clip	ASM	8664	Driven Pulley Assembly	53	1049	Decal, Caution
8	*	Moveable Face and Hub			(incl. REF. 31-39)	54	4912	Decal, Warning: Guard
9	2474	Guide Bushing	31	*	Fixed Face and Post	55	8138	Decal, Warning: Hair Entang.
10	2475	Compression Spring	32	1031	Key, 3/16sq x 1/2"	56	6958	Decal, Tire Pressure
11	*	Retaining Ring	33	2483	Spacer	57		
12	*	Fixed Face and Post	34	*	Moveable Face and Cam	58	9176	Bolt, 5/16-18 x 1"
13	9125	Washer, 3/8 Flat	35	2516	Button Insert	59	9030	Washer, 5/16 Int. Lock
14	1082	Spacer, 1" ID x 7/16	36	2480	Torsion Spring	60	10411	Adapter Plate
15	6814	Belt, Symmetrical	37	*	Fixed Cam	61	8506	Engine Standoff
16	9101	Bolt, 5/16-24 x 3/4"	38	2478	Thrust Washer	62	8679	Solenoid Assembly
17	9060	Washer, 5/16 Plain	39	2477	Retaining Ring	63	9186	Bolt, 5/16-18 x 1-1/2"
18	8745	Cover Panel	40	3403	Key, 3/16sq x 2"	64	2264	Bolt, 5/16-18 x 3/4"
19	10421	Engine, 12HP Tecumseh	41	8854	Jackshaft, 13.69"	NI	9677	Decal, Warning: Hot Surfaces
20	2449	Nut, Tinnerman	42	1119	Spacer, 5/8ID x 1/8"	NI	9678	Decal, Warning: Eng. Exhaust
21	9006	Bolt, 1/4-20 x 1/2" Whiz	43	3887	Spacer, 1" ID x 1/16	NI	5964	Decal, Oil Warning
22	8739	Cover Assembly	44	11258	Sprocket, 9T #420	* =		e Separately
		•			•		VI = Assembly	

WIRING DIAGRAM



REF	PART						
NO.	NO.	DESCRIPTION	REF	PART			
1	3611	Battery Cable, Red 9 in.	<u>NO.</u>	<u>NO.</u>	DESCRIPTION		
2	3610	Battery Cable, Black 9 in.	13	6508	Tail Light Assembly		
3	6516	Battery Cable, Black 9 in.	14	6319	Wire, Taillight Ground		
ASM	9376P	Wiring Harness (incl. 4-9)	15	6344	Start Switch		
4	9379	Wire, Taillight/Light Switch (Red)	16	6391	Light Switch Assembly		
5	9381	Wire, Taillight/Switch (Black)	17	6364	Headlight Assembly		
6	9383	Wire, Engine/Switch (Yellow)	NI	2964	Headlight Bulb		
7	6386	Wire, Batt Gnd/Switch (Black)	18	3633	Battery		
8	9385	Wire, Solenoid/Switch (Blue)	19	2093	Solenoid Jumper Wire Assembly		
9	9377	Wire, Solenoid/Light Switch (Red)	20	8216	Fuse Assembly, 15 Amp		
10	8281	Start Wire Adapter	21	2084	Solenoid		
11	8108	1/4" Male Tab Terminal	22	8202	Fuse, 15 Amp		
NI	6505	Poly Loom 43"	23	8504	Extension Wire Assembly		
NI	6897	Poly Loom 28"	NI	9389	Fuse, 10 Amp		
NI	6763	Poly Loom "Tee"	NI	6304-2	Solenoid Bracket, Black		
NI	6813	Poly Loom "Outlet"					
12	6394	Stop Switch Assembly	NI =	NI = Not Illustrated			
		· ·	ASM = Assembly				

