**ORDERING PARTS**

FAST & EASY!

1) Seek Part(s) from your models illustrated diagram, cross over REF# to PART#
2) Type PART# into sites [Search Box] at **GoKartsRus.com** TIP! - RIGHT CLICK LINK, SELECT OPEN IN NEW TAB
3) Add all needed parts to Shopping Cart | Complete "Checkout" | ✓ Done!

If a part does not come up in a Site Search, please Contact Us (include part# in email)

LOWEST PRICES!

vent for diaphragm

air flow to intake manifold

manual choke

air flow from air filter box

vacuum line

vacuum line

idle adjustment screw

fuel line connects here

air / fuel mixture screw

fuel bowl

air flow to intake manifold

fuel drain valve

fuel drain hose

fuel bowl

throttle cable

idle adjustment screw

fuel filter

fuel line

manual choke

vacuum line

vacuum line

fuel line

throttle cable

fuel filter

idle adjustment screw

View from driver side (under dump bed)

View from passenger side (under dump bed)

← FRONT OF VEHICLE

FRONT OF VEHICLE →