


REPAIR PARTS - 812-00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	8675-5	Frame - Red	72	8118	Choke Cable
2	8341	Tie Rod, 23 inch	73	2290	Ignition Key
3	3224	Tie Rod, 8-3/4 inch	74	6391	Light Switch Assembly
4	1414	Rod End - RH	75	9503	Spring, Right Wound
5	1415	Rod End - LH	76	9502	Spring, Left Wound
6	9092	Nut, 3/8-24 RH Jam	77	1436	Brake Pedal
7	9094	Nut, 3/8-24 LH Jam	78	6309	Throttle Pedal, Trimmed
8	9145	Bolt, 3/8-16 x 1-3/4"	79	9345	Throttle Cable
9	9085	Nut, 3/8-16 Toplock	80	8688-2	Seat Frame Weldment
10	8448	Compression Spring	81	6722	Seat Slide Pair
11	2457	Spindle, Right	82	2264	Bolt, 5/16-18 x 3/4"
NI	2458	Spindle, Left	83	8692	Seat Back/Bottom
12	8453	Bolt, 1/2-13 x 6-1/2"	84	6038	Steering Wheel
13	1012	Nut, 1/2-13 Toplock	85	9080	Bolt, 1/4-20 x 2-3/4"
14	4915	Tire, 145/70 x 6 Knobby	86	1689	Decal, Steering Wheel
15	3802	Inner Tube, 6"	87	6394	Stop Switch Assembly
16	1046	Nut, 5/8-11 Toplock	88	4504	Decal, Yellow Warning
17	5090	Bearing, 5/8 ID	89	8153	Decal, Age Restriction
18	9309FP	Wheel Assembly, Front (incl. 14-19)	90	8399	Decal, Seat Belt Warning
19	5950	Spanner, 5/8 ID x 2-1/8"	91	1848	Bolt, 1/4-20 x 1-1/4"
20	5157	Spacer, 5/8 ID x 3/4"	92	9834-2	Steering Crank Weldment
21	10455	Axle Weldment	93	9873	Cam Follower Bearing
22	---	---	94	1441	Decal, Front Floor Pan
23	6314H	Brake Rotor	95	6305-2	Tail Light Bracket
24	4914	Spacer, 1" ID x 9/16"	96	6508	Tail Light Assembly
25	8462	Spacer, 1" ID x 2-3/4"	97	6319	Tail Light Ground Wire
26	8373	Seat Belt, Shoulder / Lap	98	9106	Bolt, #10-32 x 1/2"
27	9188	Bolt, 1/2-13 x 1-1/2"	99	6039	Washer, #10 Internal Lock
28	6617	Bearing Flange	100	6193	Nut, #10-32 Acorn
29	3941H	Bearing, 1" ID	101	5839	Bolt, 1/4-20 x 3/4" Flanged Whiz
30	---	---	102	1447	Pedal Bolt
31	9060	Washer, 5/16" Flat	103	9091	Washer, 3/8 Flat
32	1189	Nut, 5/16-18 Toplock	104	8138	Decal, Warning: Long Hair
33	9186	Bolt, 5/16-18 x 1-1/2 GR5	105	6540	Decal, Warning: Wear Helmet
ASM	6420H	Sprocket Asm. (incl. 34-37)	106	9343	Chain, 420 x 71 Links plus Master Link
34	6282	Sprocket 420P 54T	107	2037	Master Link, 420 Chain
35	6280H	Sprocket Hub	108	8702-5	Rear Bar
36	9006	Bolt, 1/4-20 x 1/2" Whiz Flange	109	8700-5	Center Bar
37	6701	Bolt, 5/16-18 x 1-1/4" SHCS	110	8699-5	Front Bar
38	---	---	111	8701-5	Overhead Bar
39	10572	Headlight Assembly	112	8729	Arm Pad Cover
40	---	---	113	8726	Foam, 26" Gray
41	K808-02	Axle Guard Kit	114	8728	Foam, 19-1/2" Gray
42	1557H	Wheel Hub w/Studs	115	8725	Foam, 37" Gray
43	---	---	116	8463	Spacer, 1" ID x 2.625"
44	1428	Nut, 1/2-13 Cone Wheel	117	8735	Headrest
ASM	1412	Wheel Asm, Rear (incl. 45-47)	118	8730	Plastic Hose Clamp, 1-1/4" ID
45	1451	Wheel Rim, 8"	119	1876	Bolt, 1/4-20 x 5/8" Flanged Whiz
46	1430	Inner Tube, 8" (Repair Part Only)	120	2386	Bolt, 3/8-16 x 3-1/2"
47	1452	Tire, 22 x 11 - 8 Tubeless	121	6452	Bolt, 3/8-16 x 5"
48	9162	Nut, 3/4-10 Toplock	122	10490-5	Front Plate - Red
49	9176	Bolt, 5/16-18 x 1"	123	---	---
50	6573	Bolt, 5/16-18 x 1-3/4"	124	8830	Decal, Front Plate
51	9674	Spacer, 3/8 ID x 3/8"	125	3633	Battery
52	8331-2	Brake Link Weldment	126	9642-2	Battery Clamp Bar
53	9455	Spring Pin	127	9468	Nut, #10-32 Nylock Wing
54	9780	Extension Spring	128	9430	Battery Hold Down Rod
55	8197	Brake Caliper, Left	129	8673-2	Parking Brake Handle
NI	8444	Brake Caliper, Right	130	4900	Brake Handle Cover
56	8640	Brake Cable	131	1849	Bolt, 1/4-20 x 1-1/2"
57	9022	Washer, 1/2 Flat	132	9172	Bolt, 3/8 x 1/4 Shoulder
58	9174	E-Ring	133	6441	Washer, 3/8 ID Spring
59	1847	Bolt, 1/4-20 x 1"	134	8672	Parking Brake Rod
60	9057	Nut, 1/4-20 Toplock	135	6440	Nut, 5/16-18 Jam
61	1854	Washer, No. 14 Flat	136	9872	Washer, 1/4 Flat
62	1389	Bushing, 1/4" ID x 5/16	137	9871	Shoulder Bolt, 1/2 x 3
63	9160	Bolt, 1/4-20 x 7/8"	138	2257	Fairing
64	9146	Bolt, 3/8-16 x 1-1/2"	139	8734	Decal, Fairing
65	6296-2	Control Box	140	8676	Grommet
66	9528-2	Cover Plate	141	6880	End Cap, 1-1/4" Hole
67	6039	Washer, #10 Internal Lock	142	1865	Bolt, 1/4-20 x 1-3/4"
68	6046	Bolt, #10-24 x 1/2"	NI	9247R4	Assembly Instructions
69	5135	Nut, #10 Tinnerman	NI	6477	Dingo Operator's Manual
70	6344	Start Switch w/Key	NI	10735	Tecumseh Engine Manual
71	1469	Washer, Choke Cable	ASM = Assembly	NI = Not Illustrated	



ORDERING PARTS


- 1) Seek Part(s) from your models illustrated diagram, cross over REF# to PART#
- 2) Type PART# into sites [Search Box] at GoKartsRus.com TIP! - RIGHT CLICK LINK, SELECT OPEN IN NEW TAB
- 3) Add all needed parts to Shopping Cart | Complete "Checkout" | ✓Done!

If a part does not come up in a Site Search, please [Contact Us](#) (include part# in email)

FAST & EASY!


LOWEST PRICES!

CALIPER BREAKDOWN



REF. NO	PART NO	DESCRIPTION
ASM	8197	Brake Caliper (incl. 1-11)
ASM	9810	Brake Pad Svc Kit (incl. 1-3)
1	*	Anvil w/Lining
2	*	Brake Lining
3	3928	Backing Plate
4	3930	Actuator Pin
5	3931	Adjuster Pin
6	3932	Nut, Jam
7	9158	Bolt, 3/8-16 x 2-1/4"
8	9085	Nut, 3/8-16 Toplock
ASM	6534	MB-1 Service Kit (incl. 9-11)
9	*	Groove Pin
10	*	Lever
11	*	Brake Housing

TORQUE CONVERTER BREAKDOWN




REF. NO	PART NO	DESCRIPTION
1	8689	Stud, 3/8-24 x 4-1/4"
2	1130	Washer, 3/8 Split Lock
3	2468	Washer, Pilot
ASM	2594	Driver Pulley Assembly (incl. REF. 4-12)
4	*	Cover and Drive Plate
5	2472	Extension Spring
6	2470	Cam Roller
7	2471	Spring Clip
8	*	Moveable Face and Hub
9	2474	Guide Bushing
10	2475	Compression Spring
11	*	Retaining Ring
12	*	Fixed Face and Post
13	9125	Washer, 3/8 Flat
14	1082	Spacer, 1" ID x 7/16
15	6814	Belt, Symmetrical
16	9101	Bolt, 5/16-24 x 3/4"
17	9060	Washer, 5/16 Plain
18	8745	Cover Panel
19	10421	Engine, 12HP Tecumseh
20	2449	Nut, Tinnerman
21	9006	Bolt, 1/4-20 x 1/2" Whiz
22	8739	Cover Assembly

REF. NO	PART NO	DESCRIPTION
23	8600	Impeller
24	1263	Nut, 5/16-18 Flange
25	2388	Nut, 3/8-24 Hex
26	9123	Nut, 3/8-24 Toplock Hex
27	9186	Bolt, 5/16-18 x 1-1/2"
28	8908	Chassis
29	1466	Nut, 5/8-11 Flexlok Jam
30	4914	Spacer, 1" ID x 9/16
ASM	8664	Driven Pulley Assembly (incl. REF. 31-39)
31	*	Fixed Face and Post
32	1031	Key, 3/16sq x 1/2"
33	2483	Spacer
34	*	Moveable Face and Cam
35	2516	Button Insert
36	2480	Torsion Spring
37	*	Fixed Cam
38	2478	Thrust Washer
39	2477	Retaining Ring
40	3403	Key, 3/16sq x 2"
41	8854	Jackshaft, 13.69"
42	1119	Spacer, 5/8ID x 1/8"
43	3887	Spacer, 1" ID x 1/16
44	1125S	Sprocket, 9T #420

REF. NO	PART NO	DESCRIPTION
45	5090	Bearing
46	2430	Spanner
47	8194	Cap, Plastic
48	8443	Right Deck Cover
49	8924	Left Deck Cover
50	8923	Caliper Cover - Left
51	8266	Loop Clip
52	8227	Clip Nut
53	1049	Decal, Caution
54	4912	Decal, Warning: Guard
55	8138	Decal, Warning: Hair Entang.
56	6958	Decal, Tire Pressure
57	8441	Caliper Cover - Right
58	9176	Bolt, 5/16-18 x 1"
59	9030	Washer, 5/16 Int. Lock
60	10411	Adapter Plate
61	8506	Engine Standoff
62	8679	Solenoid Assembly
63	9186	Bolt, 5/16-18 x 1-1/2"
64	2264	Bolt, 5/16-18 x 3/4"
NI	9677	Decal, Warning: Hot Surfaces
NI	9678	Decal, Warning: Eng. Exhaust
NI	5964	Decal, Oil Warning

* = Not Available Separately
 ASM = Assembly NI = Not Illustrated

WIRING DIAGRAM



REF NO.	PART NO.	DESCRIPTION
1	3611	Battery Cable, Red 9 in.
2	3610	Battery Cable, Black 9 in.
3	6516	Battery Cable, Black 9 in.
ASM	9376P	Wiring Harness (incl. 4-9)
4	9379	Wire, Taillight/Light Switch (Red)
5	9381	Wire, Taillight/Switch (Black)
6	9383	Wire, Engine/Switch (Yellow)
7	6386	Wire, Batt Gnd/Switch (Black)
8	9385	Wire, Solenoid/Switch (Blue)
9	9377	Wire, Solenoid/Light Switch (Red)
10	8281	Start Wire Adapter
11	8108	1/4" Male Tab Terminal
NI	6505	Poly Loom 43"
NI	6897	Poly Loom 28"
NI	6763	Poly Loom "Tee"
NI	6813	Poly Loom "Outlet"
12	6394	Stop Switch Assembly

REF NO.	PART NO.	DESCRIPTION
13	6508	Tail Light Assembly
14	6319	Wire, Taillight Ground
15	6344	Start Switch
16	6391	Light Switch Assembly
17	6364	Headlight Assembly
NI	2964	Headlight Bulb
18	3633	Battery
19	2093	Solenoid Jumper Wire Assembly
20	8216	Fuse Assembly, 15 Amp
21	2084	Solenoid
22	8202	Fuse, 15 Amp
23	8504	Extension Wire Assembly
NI	9389	Fuse, 10 Amp
NI	6304-2	Solenoid Bracket, Black

NI = Not Illustrated
 ASM = Assembly