
LOOK UNDER ASM. SPROCKET
LOOK UNDER REAR WHEEL ASM.
LOOK UNDER FR TIRE ASM.

YELLOW JACKET

DK6 5506

1.	5406-20	FRAME - YELLOW
	5406-5	FRAME – RED
ASM	5431	TIE ROD ASM (2- 6)
2.	5430	TIE ROD 14"
3.	9092	NUT, 3/8–24 HEX JAM
4.	1414	TIE ROD END, RH
5.	1415	TIE ROD END, LH
6.	9024	NUT, 3/8–24 LH JAM
7.	9145	BOLT, 3/8-16 X 1-3/4
8.	6123	KEY, ¼ -SQ. X 3/4
9.	9146	BOLT, 3/8 –16 X 1-1/2
10.	2457	SPINDLE, RH
NI	2458	SPINDLE, LH
11.	1264	BOLT ½ 13 X 3-3/4
12.	1012	NUT ½ -13 T/ LOCK
13.	5157	SPACER 5/8 IDX 3/4
14.	1466	NUT 5/8-11 FLEX/LOCK
ASM.	9309 FP	WHEEL ASM (15-17)
15.	5090	BEARING 5/8ID1-3/8
16.	5950	SPANNER
17.	4915	TIRE 145/70 X 6
18.	3802	TUBE (REPAIR PART)
19.	G0850	LOOM 8.5" X 3"
ASM.	5428	RE WHEEL ASM, (20,21A)
20.	3548	TIRE 18/9.5 X 8
21.	1430	TUBE (REPAIR PART)
21.A	10324	RIM 8" (REPAIR PART)
22.	5416	CENTER SHAFT
23.	5417	OUTRER SHAFT
ASM.	6420	SPROCKET ASM (24-27)
24.	6282	SPROCKET 54T
25.	6280	SPROCKET HUB
26.	6701	BOLT 5/16 –18 X 1-¼
27.	9006	BOLT ¼ -20 X ½ WF
28.	2417	BRAKE DRUM
29.	3712	KEY ¼ SQ. X 1"
30.	2513	BRAKE BAND
31.	9118	PIN CLEVIS
32.	9091	WASHER FLAT 3/8
33.	9116	PIN COTTER
34.	5523	U-JOINT
NI.	10390	U-JOINT REPAIR KIT
35.	1775	KEY ¼ SQ. X 1-¼"
36.	9127	BOLT 5/16–18X 2-1/4
37.	1139	NUT5/16–18 T/LOCK
38.	5414	BEARING 1" ID 2"
39.	2265	SPACER 1" X ¾
40.	10279	KEY ¼ X .3/8
41.	1194	WASHER ¾ FLAT
42.	9162	NUT ¾-10 T/ LOCK
43.	10158	A- ARM R H
NI	10157	A-ARM L H
44.	1437	PEDALTHROTTLE
45.	9502	SPRING LH/ WOUND
46.	1846	BOLT ¼-20 X 3/4
47.	1389	BUSHING ¼ ID
48.	9057	NUT ¼ -20 T/ LOCK
49.	8251	THROTTLE CABLE
50.	2748	CABLE STOP NUT
51.	1447	BOLT 5/16–18 X 11/ 16
52.	1189	NUT 5/16-18 T/L
53.	9085	NUT 3/8-16 T/ L
54.	9503	SPRING RH WOUND
55.	1854	WASHER #14 FLAT
56.	1436	BRAKE PEDEL
57.	5435	BRAKE ROD 38 3/4
58.	5434	BRAKE ROD 10"
59.	1849	BOLT ¼ -20 X 11/2
60.	9080	BOLT ¼ -20 X 2 ¾
61.	5423	STEERING WHEEL
62.	1406	WIRING HARNESS
63.	5422	STOP WIRE
64.	8567	IDLER PULLEY
65.	8566	SPRING TORSION
66.	9674	SPACER 3/8 X 3/8
67.	8655	SEAT SLIDE PAIR
68.	5407-2	SINGLE SEAT FRAME
69.	5424	SEAT PAD
70.	2264	BOLT 5/16-18 X 3/4
71.	1263	NUT 5/16–18 WF
72.	4561	SHOCK
73.	6634	SHOCK BUSHING
74.	1046	NUT 5/8-11 T/L0CK
75.	1104	SPACER 5/8 ID X 1"
76.	5090	BEARING 5/8X 1-3/8
77.	6788	SPANNER
78.	8219	JACKSHAFT
79.	3403	KEY 3/16 SQ. X 2"
80.	1119	SPACER 5/8 ID
81.	1125S	SPROCKET 420P 9T
82.	1031	KEY 3/16 SQ. X ½
ASM.	5958	DRIVEN PULLELY (83-89)
83.	*	STAY / SHEAVE
84.	200349	BUSHING
85.	*	MOVEABLE / SHEAVE
86.	*	BUTTON NYLON
87.	*	SPRING
88.	*	CAM
89.	*	RETAINING RING
90.	5959	BELT
91.	8227	NUT (CLIP)
92.	5526	TOP COVER
93.	5527	LH COVER
94.	5528	RH COVER
95.	10293	MOUNT. STRAP
96.	6511	CHAIN
97.	9679	DECAL NO RIDERS
98.	9677	DECAL WARN.HOT
99.	5964	DECAL W/ O OIL
100.	9678	DECAL ENG/ EXH
101.	5533	ENGINE 6.O
102	1454	BOLT 5/16 –24X1- ¾
103.	1124	WASHER 5/16 SL
104.	9060	WASHER 5/16 FLAT
ASM.	5957	DRIVER (105-110)
105.	*	DRUM
106.	*	HUB
107.	*	SHOE ASSEMBLY
108.	*	MOVEABLE / SHEAVE
109.	*	BUSHING
110.	*	STAYTIONARY / SHEAVE
111.	1938	SPACER ¾ X 3/8
112.	5408-2	OVERHEAD BARLH
113.	5409-2	OVERHEAD BARRH
114	5461	SEAT BELT
115.	9022	WASHER ½ FLAT
116.	5411-2	CROSS BAR
117.	5447	SAFTY FLAG
118.	9188	BOLT 1/2–13 X 1-½
119.	6958	DECAL T/PRESS
120.	8138	DECAL L / HAIR
121.	4912	DECAL WARNING
122.	1049	DECAL DR. COVER
123.	9929	RUBBER CAP
124.	6573	BOLT 5/16 - 18 X 1-¾
125.	8826	LOOP CLIP
126.	5412	1/2 SHAFTSUPT RH
127.	5413	1/2 SHAFT SUPT LH
128.	2386	BOLT 3/8 –16 X 3-½
129.	5762	SPACER 3/8 ODX 1"
130.	5415	ROD END STAB.
131.	1449	BOLT 3/8–16 X 2.00
132.	1264	BOLT ½ 13 X 3-3/4
133.	9158	BOLT 3/8–16 X 2-½
134.	5584	DIPSTICK
135.	5585	FILL TUBE
NI	5586	O-RING, FILL TUBE
NI	5587	CLIP, FILL TUBE
NI	5405	DECAL Y J 8"
NI	4504	DECAL WARNING
NI	6540	DECAL HELMET
NI	8154	DECAL NO CHILD
NI	2832	DECAL NO PASS

MANUALS NOT SHOWN

4350AV	OPERATERS MANUAL
9233R2	ADDENDUM OM BRAKE AND TAV
9283R3	ADDEM OM SEATBELTS
10042	FOAM PACK

ASM	=	ASSEMBLY
NI	=	NOT ILLUSTATED
*	=	NOT SOLD SEPARATELY

ORDERING PARTS

FAST & EASY

LOWEST PRICES!

1) Seek Part(s) from your models illustrated diagram, cross over REF# to PART#

2) Type PART# into sites [Search Box] at GoKartsRus.com TIP! - RIGHT CLICK LINK, SELECT OPEN IN NEW TAB

3) Add all needed parts to Shopping Cart | Complete "Checkout" | ✓Done!

If a part does not come up in a Site Search, please Contact Us (include part# in email)